Assembly Instructions:

FIG. 3

Step 3. Attach the Rim (#7) to the Main Board (#1) using two Bolts (#5), one Metal Support (#2) and two Nuts (#9).





FIG. 4

Step 4. Install the Net (#8) to the Rim (#7). You are now ready to play!





ELECTRONIC BASKETBALL PRO

Item # 19970




⚠ WARNING:

CHOKING HAZARD--Small parts. Not for children under 3 yrs.

Franklin Sports Inc. Stoughton, MA 02072 Made in China


For replacement parts, call 1-781-341-5178 or 1-800-225-8649 or visit www.franklinsports.com



Assembly Instructions:

FIG. 1

Step 1. Locate the battery compartment and insert (3) "AAA" Alkaline Batteries (Not included)



Requires 3 "AAA" size batteries (not included) Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

FIG. 2

Step 2. Attach the Hooks (#6) to the Main Board (#1) using two Plastic Bolts (#3) and four Nuts (#4).

